

Hand Lenses & Magnifiers

Westernex Hand Lens 21mm

Highly corrected triple lens system guarantees superb image quality - sharp and distinct, even under high magnification. Precision ground and highly polished lenses. Double, high impact robust design. The swing away, chrome-plated base protects the lens and serves as a hand grip.

SKU	SIZE	
1139-00800	10x Triplet	
1139-00801	20x Triplet	



LED Hand Lens 10x

Highly corrected triple lens system guarantees superb image quality - sharp and distinct, even under high magnification. Precision ground and highly polished lenses. Double, high impact robust design. The swing away, chrome-plated base protects the lens and serves as a hand grip.

SKU	DESCRIPTION	SIZE
1139-00014	LED	10x Triplet





LED/UV Hand Lens 10x

Highly corrected triple lens system guarantees superb image quality - sharp and distinct, even under high magnification. Precision ground and highly polished lenses. Double, high impact robust design. The swing away, chrome-plated base protects the lens and serves as a hand grip. The UV light is short wave.

SKU	DESCRIPTION	SIZE	
1139-00015	LED/UV	10x Triplet	







Bausch & Lomb Hand Lens

Incorporates 3 separate glass lenses, bonded together to form a compound lens. Very distinct magnified image without distortion. Sometimes these are referred to as "Jewellers Loupes".

- Hastings Triplet 7x: focal distance 1.5" (3.9cm), dioptre 28D, diameter: 19.8 mm
- Hastings Triplet 10x: focal distance: 1" (2.5 cm), dioptre: 40D, diameter: 15.8 mm
- Hastings Triplet 14x: focal distance 0.8" (2.0 cm), dioptre 56D, diameter: 12.5 mm
- Hastings Triplet 20x: focal distance: 0.5" (1.3 cm), dioptre: 80D, diameter: 8.3 mm

SKU	SIZE
1139-00703	7x Triplet
1139-00700	10x Triplet
1139-00701	14x Triplet
1139-00702	20x Triplet




Hand Lenses & Magnifiers

Peak 2001 Pocket Microscope

The outstanding features of this pocket microscope are: very sharp resolving power throughout its field of view, unbelievably bright and light in weight. It is a practical and convenient pocket microscope for the technocrat.

To focus the microscope, hold it so that the notch at the tip of the acrylic cylinder of the microscope faces towards you, place the center of the object lens above the specimen and while tilting the cylinder forward and backward with your eye on the eye-piece lens, fix the cylinder and adjust to the best angle which can give the sharpest image.

SKU	MAGNIFICATION	FIELD OF VIEW
PPM25	25X	3.30mm
PPM50	50X	2.00mm





Caution: Do not look directly at the sun or strong light with this device. There is a possibility that your eyes may be injured. Also be careful not to leave the magnifier where the sun or strong light shine upon. There is a danger of catching fire by the lens brought to focus.

Peak 2036 Pocket Measuring Microscope

Pocket measuring microscope with reticle. New selected the models of 25X and 50X pocket microscope series, with incorporated scales into their lens barrel. The reticle is cross hair with horizontal scale.

To focus the microscope, hold it so that the notch at the tip of the acrylic cylinder of the microscope faces towards you, place the center of the object lens above the specimen and while tilting the cylinder forward and backward with your eye on the eye-piece lens, fix the cylinder and adjust to the best angle which can give the sharpest image.

SKU	MAGNIFICATION	FIELD OF VIEW	MIN.S CALE DIVISION	RANGE
PPM25SCALE	25X	3.30mm	0.05mm	3.0mm
PPM50SCALE	50X	2.00mm	0.02mm	1.6mm



206 Supplying Mining & Exploration Worldwide



Perth Main Warehouse Kalgoorlie Warehouse

66 Truganina Rd, Malaga, Western Australia 6090 +61 (0) 8 9209 8500 perth@westernex.com.au

18 Kinclaven Way, Broadwood, Kalgoorlie, Western Australia 6430 +61 (0) 8 9091 1152 kalgoorlie@westernex.com.au

Brisbane Warehouse

14 Hasp St, Seventeen Mile Rocks, Queensland 4073 +61 (0) 7 3376 2422 brisbane@westernex.com.au

Mt Isa Warehouse

13 Ryan Rd, (Entry off Davis Rd) Mt Isa, Queensland 4825 +61 (0)7 4743 2122 mtisa@westernex.com.au

Orange Warehouse

72 Astill Drive, Orange, NSW, 2800 +61 (0) 7 3376 2422 brisbane@westernex.com.au









